



Illustrated Parts List

Model Series

127300

TYPE NUMBERS
0036 through 0215.









TABLE OF CONTENTS

Air Cleaner	7
Blower Housing	8
Camshaft	2
Carburetor	5
Controls	6
Crankcase Cover	3
Crankshaft	2
Cylinder	2
Cylinder Head	4
Electric Starter	6
Exhaust System	7
Flywheel	8
Fuel Supply	5
Gear Reduction	3
Governor Spring	6
Ignition	6
Kits/Gaskets - Carburetor	5
Kits/Gaskets - Engine	2
Kits/Gaskets - Valve	4
Lubrication	3
Piston Group	2
Rewind Starter	78



PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

Assemblies include all parts shown in frames.


08/25/2012






125

NOTE: This Illustration Represents Several Carburetors. Parts Shown May Not Be Included In All Kits.




365




125D


NOTE: This Illustration Represents Several Carburetors. Parts Shown May Not Be Included In All Kits.




118D




121 CARBURETOR OVERHAUL KIT



121D CARBURETOR OVERHAUL KIT





972



957

190



958


240








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.


5720-5

Assemblies include all parts shown in frames.

08/25/2012







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699505	Cylinder Assembly ----- Note ----- 699490 Cylinder- Assembly Used on Type No(s). 0116, 0120, 0181.		797078	Crankshaft Used on Type No(s). 0116, 0141, 0161, 0181. 797070 Crankshaft Used on Type No(s). 0112, 0130, 0145, 0182, 0211. 797076 Crankshaft Used on Type No(s). 0113. 795927 Crankshaft (Used After Code Date 06051600). Used on Type No(s). 0049, 0134, 0139, 0152, 0153, 0163, 0189, 0192, 0195, 0197, 0203. 699444 Crankshaft (Used Before Code Date 06051700). Used on Type No(s). 0049, 0134, 0139, 0152, 0153, 0163.	23	699488	Flywheel
2	796961	Kit-Bushing/Seal (Magneto Side)				23A	699514	Flywheel Used on Type No(s). 0118, 0126, 0159, 0169, 0215.
3	299819S	Seal-Oil (Magneto Side)				24	796335	Key-Flywheel
5	797439	Head-Cylinder (Metric)				25	795429	Piston Assembly (Standard) ----- Note ----- 799064 Piston Assembly (.020" Oversize)
7	698210	Gasket-Cylinder Head				26	791969	Ring Set (Standard) (Used After Code Date 05030800). ----- Note ----- 499631 Ring Set (Standard) (Used Before Code Date 05030900). 791324 Ring Set (.020" Oversize) (Used After Code Date 05030800). 692786 Ring Set (.020" Oversize) (Used Before Code Date 05030900).
11	692600	Tube-Breather (Flat Panel Air Cleaner)				27	691866	Lock-Piston Pin
11A	693647	Tube-Breather (High Mount Air Cleaner)				28	499423	Pin-Piston
12	699485	Gasket-Crankcase				29B	798813	Rod-Connecting
13	699482	Screw (Cylinder Head)				30	791584	Dipper-Connecting Rod
15	691686	Plug-Oil Drain (Square Head)				32	691664	Screw (Connecting Rod)
15A	691682	Plug-Oil Drain (Flush)				32A	695759	Screw (Connecting Rod)
15B	792750	Plug-Oil Drain	17	798538	Bearing-Ball	32B	797437	Screw (Connecting Rod)
16	797072	Crankshaft ----- Note ----- 797075 Crankshaft Used on Type No(s). 0111, 0114, 0126, 0131, 0154, 0159, 0171, 0173, 0183, 0184, 0190, 0201, 0209, 0215. 699442 Crankshaft Used on Type No(s). 0127, 0138, 0150, 0169, 0170, 0176.	17B	99158	Bearing-Ball	33	499642	Valve-Exhaust
			18	699804	Cover-Crankcase ----- Note ----- 699696 Cover- Crankcase Used on Type No(s). 0112. 699804 Cover- Crankcase (Used After Code Date 07070200). Used on Type No(s). 0152, 0153, 0203.	34	795443	Valve-Intake
			18A	699672	Cover-Crankcase	35	691304	Spring-Valve (Intake)
			18B	699761	Cover-Crankcase ----- Note ----- 699761 Cover- Crankcase (Used Before Code Date 07070300). Used on Type No(s). 0152, 0153, 0203.	36	691304	Spring-Valve (Exhaust)
			20	692550	Seal-Oil (PTO Side)			
			20A	694171	Seal-Oil (PTO Side)			
			21	281658S	Cap-Oil Fill			
			22	799318	Screw (Crankcase Cover/Sump)			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5720-9 Assemblies include all parts shown in frames. 08/25/2012

127300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
37	699661	Guard-Flywheel	83	690374	Shaft-Auxiliary Drive (Used Before Code Date 06051700).	97	690024	Shaft-Throttle
40	692194	Retainer-Valve				97C	797628	Shaft-Throttle
45	690977	Tappet-Valve				98	398185	Kit-Idle Speed
46	693404	Camshaft	83A	792756	Shaft-Auxiliary Drive (Used After Code Date 06051600).	98C	797156	Kit-Idle Speed
46A	696813	Camshaft				104C	797622	Pin-Float Hinge
51	692555	Gasket-Intake	84	691121	Plug-Breather	105A	797139	Valve-Float Needle
51A	791718	Gasket-Intake	84A	792759	Plug-Breather	108	692567	Valve-Choke
55		Housing-Rewind Starter (Used After Code Date 11123100). (Not Serviced Separate. Service With Rewind Assembly.)	85	692551	Screw (Gear Cover to Gear Reduction) (Used Before Code Date 06051700).	----- Note ----- 699111 Valve-Choke Used on Type No(s). 0127, 0138, 0150, 0169, 0170, 0176.		
		----- Note ----- 791848 Housing-Rewind Starter (Used After Code Date 08030200 and Before Code Date 12010100). 691422 Housing-Rewind Starter (Used Before Code Date 08030300).	85A	690711	Screw (Gear Cover to Gear Reduction) (Used After Code Date 06051600).	109	690023	Shaft-Choke
			86	690608	Cover-Gear (Used Before Code Date 06051700).	109A	693628	Shaft-Choke
58	693389	Rope-Starter (Used After Code Date 08030200).	86A	795647	Cover-Gear (Used After Code Date 08010100).	109C	790624	Shaft-Choke
		----- Note ----- 66574 Rope-Starter (Used Before Code Date 08030300).			----- Note ----- 792748 Cover-Gear (Used After Code Date 06051600 and Before Code Date 08010200).			
60	490652	Grip-Starter Rope (2 Piece)	87	691582	Seal-Gear Reduction (Used Before Code Date 06051700).			
65	699228	Screw (Rewind Starter) (Metric)	87A	792752	Seal-Gear Reduction (Used After Code Date 06051600).			
78	699205	Screw (Flywheel Guard)	88	691600	Gasket-Gear Reduction Cover			
79	694511	Case-Gear Reduction (Used Before Code Date 06051700).	88A	792760	Gasket-Gear Reduction Cover			
79A	792746	Case-Gear Reduction (Used After Code Date 06051600).	79	694511	Case-Gear Reduction			
80	792755	Gasket-Gear Case	82	690369	Screw (Gear Reduction Case)			
82	690369	Screw (Gear Reduction Case) (Used Before Code Date 06051700).	82A	790197	Screw (Gear Reduction Case)			
82A	790197	Screw (Gear Reduction Case) (Used Before Code Date 06051700).	83	690374	Shaft-Auxiliary Drive			
82B	792753	Screw (Gear Reduction Case) (Used After Code Date 06051600).	84	691121	Plug-Breather			
			85	692551	Screw (Gear Cover to Gear Reduction)			
			86	690608	Cover-Gear			
			87	691582	Seal-Gear Reduction			
			88	691600	Gasket-Gear Reduction Cover			
			95	691636	Screw (Throttle Valve)			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5720-10 Assemblies include all parts shown in frames. 08/25/2012

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
117	697355	Jet-Main (Standard) ----- Note ----- 498976 Jet-Main (Standard) Used on Type No(s). 0127, 0150, 0169, 0170, 0176. 498975 Jet-Main (Standard) (Used Before Code Date 10090100). Used on Type No(s). 0138. 697355 Jet-Main (Standard) (Used Before Code Date 12010100). Used on Type No(s). 0133, 0134, 0189, 0202, 0207.	118	494870	Jet-Main (High Altitude) ----- Note ----- 694975 Jet-Main (High Altitude) Used on Type No(s). 0127, 0150, 0169, 0170, 0176. 497466 Jet-Main (High Altitude) (Used Before Code Date 10090100). Used on Type No(s). 0138. 494870 Jet-Main (High Altitude) (Used Before Code Date 12010100). Used on Type No(s). 0133, 0134, 0189, 0202, 0207.	125	697028	Carburetor Used on Type No(s). 0112, 0113, 0123, 0157, 0174, 0198, 0205. 697028 Carburetor (Used Before Code Date 12010100). Used on Type No(s). 0133, 0134, 0189, 0202, 0207.
117D	798661	Jet-Main (Standard) ----- Note ----- 798661 Jet-Main (Standard) (Used After Code Date 10083100). Used on Type No(s). 0138. 798661 Jet-Main (Standard) (Used After Code Date 11123100). Used on Type No(s). 0133, 0134, 0189, 0202, 0207.	118D	798660	Jet-Main (High Altitude) ----- Note ----- 497466 Jet-Main (High Altitude) (Used After Code Date 10083100). Used on Type No(s). 0138. 798660 Jet-Main (High Altitude) (Used After Code Date 11123100). Used on Type No(s). 0133, 0134, 0189, 0202, 0207.	125D	798653	Carburetor ----- Note ----- 591308 Carburetor (Used After Code Date 11123100). Used on Type No(s). 0133, 0134, 0189, 0202, 0207.
						127	691739	Plug-Welch ----- Note ----- 694468 Plug-Welch Used on Type No(s). 0127, 0150, 0169, 0170, 0176.
						127A	691585	Plug-Welch
						127E	797633	Plug-Welch
						130	691181	Valve-Throttle
						130A	691203	Valve-Throttle Used on Type No(s). 0127, 0138, 0150, 0169, 0170, 0176.
			121	792006	Kit-Carburetor Overhaul			
			121D	797634	Kit-Carburetor Overhaul			
			122	795643	Spacer-Carburetor (Black) ----- Note ----- 795208 Spacer- Carburetor (Grey/Coffee)			

127300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
130D	797630	Valve-Throttle	163A	792870	Gasket-Air Cleaner (High Mount Air Cleaner)	268	691025	Casing-Control Wire (Cut to Required Length)
133	398187	Float-Carburetor				269	691026	Wire-Control (Cut to Required Length)
133B	797136	Float-Carburetor	163B	696024	Gasket-Air Cleaner (Flat Panel Air Cleaner)	270	691027	Nut (Control Wire Casing)
134	398188	Kit-Needle/Seat				271	691028	Lever-Control
137	693981	Gasket-Float Bowl	170	699818	Stud (Crankcase Cover)	271A	694256	Lever-Control
137C	797625	Gasket-Float Bowl	186	692317	Connector-Hose	276	271716	Washer-Sealing
146	690979	Key-Timing	187	791766	Line-Fuel (Cut to Required Length)	276C	797632	Washer-Sealing
155	797442	Plate-Cylinder Head (Metric) (Used After Code Date 09061700).				281	793122	Panel-Control
		----- Note -----	187A	791867	Line-Fuel (Molded)	286	794185	Module-Oil Sensor
		698214 Plate-Cylinder Head (SAE) (Used Before Code Date 09061800).	188	699479	Screw (Control Bracket)	287	699234	Screw (Dipstick Tube)
161	699207	Base-Air Cleaner (Flat Panel Air Cleaner)	190	699220	Screw (Fuel Tank)	300	693593	Muffler
		----- Note -----	192	797440	Adjuster-Rocker Arm (Metric) (Used After Code Date 09061700).	300A	797433	Muffler
		699504 Base-Air Cleaner (Flat Panel Air Cleaner) Used on Type No(s). 0169, 0170.				300E	791595	Muffler
						304	699598	Housing-Blower
			209	692571	Spring-Governor ----- Note -----	305	699481	Screw (Blower Housing)
					693206 Spring-Governor Used on Type No(s). 0111, 0114, 0116, 0125, 0141, 0181, 0183, 0184, 0209, 0211.	306	795334	Shield-Cylinder
					693710 Spring-Governor Used on Type No(s). 0207.	307	699483	Screw (Cylinder Shield)
			209A	691278	Spring-Governor	309	694504	Motor-Starter
			219	693578	Gear-Governor	310	690323	Screw (Starter Motor)
			220	691724	Washer (Governor Gear)	311	497608	Brush Set
			222D	793107	Bracket-Control (Variable Speed)	332	591988	Nut (Flywheel)
			222F	793100	Bracket-Control (Fixed Speed)	333	796964	Armature-Magneto
						334	699477	Screw (Magneto Armature)
			227	794367	Lever-Governor Control	337	491055S	Plug-Spark (Resistor)
			238	691300	Valve-Cap			----- Note -----
			240	298090S	Filter-Fuel			691043 Plug-Spark (EMS)
			265	691024	Clamp-Casing	346	699203	Screw (Spark Arrestor) (Metric)
			267	699492	Screw (Casing Clamp)			----- Note -----
								690661 Screw (Spark Arrestor) (SAE)
						347	697854	Switch-Rocker ----- Note -----
								795333 Switch-Rocker Used on Type No(s). 0122, 0139, 0154, 0156, 0171, 0195.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5720-12 Assemblies include all parts shown in frames. 08/25/2012

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
356	693651	Wire-Stop	459		Pawl-Ratchet (Used After Code Date 11123100). (Not Serviced Separate. Service With Rewind Assembly.) ----- Note ----- 281505S Pawl- Ratchet (Used Before Code Date 12010100).	597		Screw (Pawl Friction Plate) (Used After Code Date 11123100). (Not Serviced Separate. Service With Rewind Assembly.) ----- Note ----- 691696 Screw (Pawl Friction Plate) (Used Before Code Date 12010100).
356A	692390	Wire-Stop				601	791850	Clamp-Hose
356B	692602	Wire-Stop				608C	591301	Starter-Rewind
356C	695630	Wire-Stop				613	791972	Screw (Muffler)
356E	695814	Wire-Stop				613A	699481	Screw (Muffler)
356K	791765	Wire-Stop	467	691668	Knob-Air Cleaner Used on Type No(s). 0169. ----- Note ----- 695730 Alternator Used on Type No(s). 0169.	613B	799081	Screw (Muffler) (Metric) ----- Note ----- 697812 Screw (Muffler) (SAE)
358	791797	Gasket Set-Engine				615	692576	Retainer-Governor Shaft
361	691693	Screw (Starting Switch)				616	692547	Crank-Governor
363	19203	Puller-Flywheel				619	699481	Screw (Cylinder Head Plate)
364	695693	Terminal-Oil Plug				621	692310	Switch-Stop
365	699484	Screw (Carburetor)	474	793640	Alternator Used on Type No(s). 0126. ----- Note ----- 695730 Alternator Used on Type No(s). 0126.	632	693408	Spring/Link- Mechanical Governor
383	19576S	Wrench-Spark Plug				633	693867	Seal-Choke/Throttle Shaft
415	693463	Plug				633A	691321	Seal-Choke/Throttle Shaft
415B	792749	Plug				635	692076	Boot-Spark Plug
425	699208	Screw (Air Cleaner Cover)				635A	798619	Boot-Spark Plug
427	798458	Nut (Control Bracket) (Metric) ----- Note ----- 694255 Nut (Control Bracket) (SAE)	500B	691086	Washer (Key Switch)	643	696264	Retainer-Air Filter
			503	691532	Strap-Starter	652	699755	Screw (Support Bracket)
			504	695383	Washer Set-Friction	652A	699481	Screw (Support Bracket)
			505	691251	Nut (Governor Control Lever)	663	699206	Screw (Control Panel)
445	491588S	Filter-Air Cleaner Cartridge (Flat Panel)	510	499308	Drive-Starter	664	691087	Nut (Key Switch)
445A	697029	Filter-Air Cleaner Cartridge (High Mount)	513	692024	Drive-Clutch			
455	591302	Cup-Flywheel (Used After Code Date 11123100). ----- Note ----- 692591 Cup-Flywheel (Used Before Code Date 12010100).	522	697689	Plug-Dipstick/Fill			
			523	693618	Dipstick			
			524	281370S	Seal-Dipstick Tube			
			524	281370S	Seal-Dipstick Tube			
456		Plate-Pawl Friction (Used After Code Date 11123100). (Not Serviced Separate. Service With Rewind Assembly.) ----- Note ----- 692299 Plate-Pawl Friction (Used Before Code Date 12010100).	535	696263	Filter-Air Cleaner Foam			
			552	692346	Bushing-Governor Crank			
			562	691119	Bolt (Governor Control Lever)			
			577	690795	Cable-Starter			
			578	692306	Wire Assembly			
			579	691029	Nut (Starter Cable)			

127300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
668	694257	Spacer	823	791972	Screw (Muffler Adapter)	914A	797444	Screw (Rocker Cover)
675	691261	Washer (Brush Retainer)	830	797441	Stud-Rocker Arm (Metric) (Used After Code Date 09061700).			(Quantity 1, Top Or Center) (Metric) (Used After Code Date 09061700).
676	796956	Deflector-Muffler			----- Note -----			----- Note -----
676A	697816	Deflector-Muffler			694544 Stud-Rocker Arm (SAE) (Used Before Code Date 09061800).			692557 Screw (Top) (SAE) (Used Before Code Date 09061800).
676B	395700	Deflector-Muffler				914B	697551	Screw (Rocker Cover)
677	699203	Screw (Muffler Deflector) (Metric) ----- Note ----- 690661 Screw (Muffler Deflector) (SAE)	832	693583	Guard-Muffler			(Center) (SAE) (Used Before Code Date 09061800).
677A	699776	Screw (Muffler Deflector)	832A	697818	Guard-Muffler			
689		Spring-Friction (Used After Code Date 11123100). (Not Serviced Separate. Service With Rewind Assembly.) ----- Note ----- 691855 Spring- Friction (Used Before Code Date 12010100).	832B	696516	Guard-Muffler	920	691656	Solenoid-Starter
			832D	796240	Guard-Muffler	957	792647	Cap-Fuel Tank (Fresh Start) ----- Note ----- 795027 Cap-Fuel Tank (Text Free)
			835	797458	Bracket-Wire Harness	957A	799719	Cap-Fuel Tank (Carbon In Cap)
			836	699203	Screw (Muffler Guard)	958	698180	Valve-Fuel Shut Off
			836A	699632	Screw (Muffler Guard)	961	698304	Screw (Air Cleaner Bracket)
			836B	791972	Screw (Muffler Guard)	967	493537S	Filter-Pre Cleaner (Flat Panel)
			836C	699234	Screw (Muffler Guard)	967A	273356S	Filter-Pre Cleaner (High Mount)
			836D	699204	Screw (Muffler Guard)			
692	690572	Spring-Detent	836E	699755	Screw (Muffler Guard)	968	692584	Cover-Air Cleaner (Flat Panel Air Cleaner)
692B	797624	Spring-Detent	842	691031	Seal-O Ring (Dipstick Tube)	968A	693460	Cover-Air Cleaner (High Mount)
697	793567	Screw (Starter Motor)	843	695588	Sleeve-Lever	971	798649	Screw (Air Cleaner Base) (Metric) ----- Note ----- 690370 Screw (Air Cleaner Base) (SAE)
717	693462	Bracket-Air Cleaner	847	693617	Dipstick/Tube Assembly	971A	591307	Screw (Air Cleaner Base) (Used After Code Date 11123100).
718	690959	Pin-Locating	851	493880S	Terminal-Spark Plug			----- Note ----- 690349 Screw (Air Cleaner Base) (Used Before Code Date 12010100).
725	792874	Shield-Heat	863	699229	Bracket-Muffler			
727	698039	Cover-Starter Drive	864	699232	Adapter-Muffler			
728	699491	Screw (Heat Shield)	868	795440	Seal-Valve			
732	699200	Screw (Starter Drive Cover)	875	591306	Base-Air Cleaner (High Mount) (Used After Code Date 11123100).			
741	695087	Gear-Timing			----- Note ----- 697030 Base-Air Cleaner (High Mount) (Used Before Code Date 12010100).			
742	692564	Retainer-E Ring						
746	790278	Gear-Idler	883	691893	Gasket-Exhaust			
773	694258	Retainer	883A	692237	Gasket-Exhaust			
783	692353	Gear-Pinion	890	790203	Bracket-Support			
789	797457	Harness-Wiring	892A	692318	Key-Switch			
797	691029	Nut (Brush Retainer)	914	699481	Screw (Rocker Cover) (Bottom)			
799	699202	Screw (Oil Sensor)						
801	694482	Cap-Drive						
802	691286	Cap-End						
813	690635	Clamp						
819	699233	Screw (Muffler Bracket)						
819A	699230	Screw (Muffler Bracket)						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5720-14 Assemblies include all parts shown in frames. 08/25/2012

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
971B	699234	Screw (Air Cleaner Base)	1051	691265	Ring-Retaining	1211		Pulley/Spring Assembly
972	799863	Tank-Fuel	1052	790141	Sensor-Oil			(Pulley)
975	796611	Bowl-Float	1054	280275	Cable-Tie			(Used After Code Date 11123100).
975C	797631	Bowl-Float	1058	277040	Operator's Manual			(Not Serviced Separate. Service With Rewind Assembly.)
987B	797629	Seal-Throttle Shaft	1070	699201	Screw (Flywheel Fan)			----- Note -----
990A	691959	Key Set	1090	691293	Retainer-Brush			791849 Pulley/Spring Assembly
993	694088	Gasket-Cylinder Head Plate	1095	791798	Gasket Set-Valve			(Used After Code Date 08030200 and Before Code Date 12010100).
994	399541	Arrester-Spark	1119	699772	Screw (Alternator)			498144 Pulley/Spring Assembly
1005	692592	Fan-Flywheel			Pulley/Spring Assembly			(Pulley)
1005A	794273	Fan-Flywheel	1210		(Used After Code Date 11123100).			(Used Before Code Date 08030300).
1022	691890	Gasket-Rocker Cover			(Not Serviced Separate. Service With Rewind Assembly.)			
1023	499924	Cover-Rocker Arm			----- Note -----			
1026	790287	Rod-Push			791849 Pulley/Spring Assembly	1230	699847	Stud (Control Bracket)
1029	797443	Arm-Rocker (Metric) (Used After Code Date 09061700).			(Used After Code Date 08030200 and Before Code Date 12010100).	1305	699691	Screw (Oil Sensor Module)
		----- Note -----			498144 Pulley/Spring Assembly	1319	794467	Label-Warning
		691230 Arm-Rocker (SAE) (Used Before Code Date 09061800).			(Pulley) (Used Before Code Date 08030300).	1319A	797669	Label-Warning
1034	691343	Guide-Push Rod				1330	272147	Repair Manual
1036		Label-Emissions (Available From An Authorized Briggs & Stratton Service Dealer)						

Not for
Reproduction

